

01



**This guide was
revised in March 2023**

Please check
woodsolutions.com.au/publications
to ensure you have the latest edition

Timber-framed Construction for Townhouse Buildings Class 1a

*Design and construction guide for BCA compliant
sound and fire-rated construction*



WoodSolutions Technical Design Guides

A growing suite of information, technical and training resources, the Design Guides have been created to support the use of wood in the design and construction of the built environment.

Each title has been written by experts in the field and is the accumulated result of years of experience in working with wood and wood products.

Some of the popular topics covered by the Technical Design Guides include:

- Timber-framed construction
- Building with timber in bushfire-prone areas
- Designing for durability
- Timber finishes
- Stairs, balustrades and handrails
- Timber flooring and decking
- Timber windows and doors
- Fire compliance
- Acoustics
- Thermal performance

More WoodSolutions Resources

The WoodSolutions website provides a comprehensive range of resources for architects, building designers, engineers and other design and construction professionals.

To discover more, please visit

www.woodsolutions.com.au

The website for wood.



WoodSolutions is an industry initiative designed to provide independent, non-proprietary information about timber and wood products to professionals and companies involved in building design and construction.

WoodSolutions is resourced by Forest and Wood Products Australia (FWPA). It is a collaborative effort between FWPA members and levy payers, supported by industry peak bodies and technical associations.

This work is supported by funding provided to FWPA by the Commonwealth Government.

ISBN 978-1-920883-78-2

Researcher:

Timber Development Association (NSW)
Suite 604, 486 Pacific Highway
St Leonards NSW 2065

Printed: May 2010

Revised: May 2012, August 2012, September 2015, February 2021, March 2023

**© 2023 Forest and Wood Products Australia Limited.
All rights reserved.**

These materials are published under the brand WoodSolutions by FWPA.

IMPORTANT NOTICE

Whilst all care has been taken to ensure the accuracy of the information contained in this publication, Forest and Wood Products Australia Limited and WoodSolutions Australia and all persons associated with them (FWPA) as well as any other contributors make no representations or give any warranty regarding the use, suitability, validity, accuracy, completeness, currency or reliability of the information, including any opinion or advice, contained in this publication. To the maximum extent permitted by law, FWPA disclaims all warranties of any kind, whether express or implied, including but not limited to any warranty that the information is up-to-date, complete, true, legally compliant, accurate, non-misleading or suitable.

To the maximum extent permitted by law, FWPA excludes all liability in contract, tort (including negligence), or otherwise for any injury, loss or damage whatsoever (whether direct, indirect, special or consequential) arising out of or in connection with use or reliance on this publication (and any information, opinions or advice therein) and whether caused by any errors, defects, omissions or misrepresentations in this publication. Individual requirements may vary from those discussed in this publication and you are advised to check with State authorities to ensure building compliance as well as make your own professional assessment of the relevant applicable laws and Standards.

The work is copyright and protected under the terms of the Copyright Act 1968 (Cwth). All material may be reproduced in whole or in part, provided that it is not sold or used for commercial benefit and its source (Forest & Wood Products Australia Limited) is acknowledged and the above disclaimer is included. Reproduction or copying for other purposes, which is strictly reserved only for the owner or licensee of copyright under the Copyright Act, is prohibited without the prior written consent of FWPA.

WoodSolutions Australia is a registered business division of Forest and Wood Products Australia Limited.

Table of Contents

Introduction	4
Step 1 – High-Level BCA Design Issues	7
1.1 Determine the Class of Building	7
1.2 BCA Compliance – Deemed to Satisfy Provisions or Alternative Solutions	7
1.3 Fire and Sound Separation in Buildings	8
Step 2 – Define BCA Sound-Design Requirements	10
2.1 Utilising the Deemed to Satisfy Provisions for Sound Design	10
2.2 Determine Sound-Insulation Requirements In Separating Walls	11
2.3 Treatment of Services Relevant to Timber-Framed Construction	12
2.4 The Next Step	12
Step 3 – Improve and Upgrade Sound Performance	13
3.1 Checking and Adjusting the Building Design to Reduce Sound Transmission	13
3.2 Strategies for Improving Sound Performance in Construction.	14
3.3 The Next Step	16
Step 4 – Define Fire-Design Requirements	17
4.1 Utilising the Deemed to Satisfy Provisions for Fire Design	17
4.2 Fire Resistance Levels of Wall Elements	17
4.3 The Next Step	19
Step 5 – Select Sound- and Fire-Rated Timber Construction Systems	20
5.1 Principles for Achieving Fire Resistance Levels in Timber-Framed Construction	20
5.2 Principles for Achieving Sound Insulation in Timber-Framed Construction	22
5.3 Sound- and Fire-Rated Wall Construction Systems	22
5.4 Solid-Timber Construction Joints	23
5.5 Treatment of Roof Voids	29
5.6 Separation Wall Abutting External Walls	33
5.7 Steel Columns in Separating Walls.	35
5.8 Horizontal Projection of a Floor and Separating Wall in Neighbouring Buildings	38
5.9 Fire Separation of Garage Top Dwellings	39
Step 6 – Further Design Assistance (Appendices)	40
Appendix A – Resolving Structural Design Considerations and Construction Practices	40
Appendix B – Design References	42
Appendix C – Glossary	43

Introduction

This Guide covers fire and sound.

Fire and sound are important issues in residential construction. Sound insulation tends to govern the choice of construction system because of its daily impact on the building occupants' quality of life. In contrast, fire-resisting construction is essential for protecting against extreme events.

This Guide aims to assist in both areas. It is specifically written for use by designers, specifiers, builders and certifying authorities for timber-framed Class 1a attached buildings, separated by a fire-resisting and acoustic wall. These buildings include row houses, terrace houses, duplex, townhouses and villa units.

Scope

For timber-framed construction, this Guide demonstrates compliance with targeted fire safety and sound-insulation Performance Requirements in the Building Code of Australia (BCA) for building classified as Class 1a attached buildings. These buildings include row houses, terrace houses, duplex, townhouses and villa units. The Guide does not cover Class 2 or 3 buildings that may be row houses, terrace houses, duplex, townhouses and villa units or buildings using fire-protected timber systems, as the BCA has different requirements for these buildings. Refer to other WoodSolution guides for information on these buildings.

Specific areas of performance addressed include:

- Providing sound insulation in walls between dwellings.
- Protection against spread of fire both between dwellings and on external walls (where required).

The Guide primarily focuses on double stud timber-framed fire and acoustically rated separating wall solutions (Figure 1).



Figure 1: Double stud timber-framed separating wall.

Although there are other solutions, such as 'Partiwall' and textile-based systems that can be used for timber-framed Class 1a building (Figure 2) these systems are proprietary and left to the manufacturer of these systems to provide information.

Furthermore, the Guide does not deal with fire detection and early warning in buildings (including smoke alarms), heating appliance issues, bushfires or fire in alpine areas.

This Guide provides certified construction details by utilising the BCA's Deemed to Satisfy Provisions. In addition, guidance beyond BCA minimum requirements is provided for those wanting to improve and upgrade sound performance.

Although national, some BCA provisions differ by state. It's vital to know key variations for your area.



(a) Speedpanel separating wall



(b) Knauf/USG Boral Partiwall

Figure 2: Proprietary timber-based separating walls. (Images: Speedpanel and USG Boral)

Regulatory Differences Between States and Territory of Australia

This publication focuses on current BCA requirements. From time to time, State-based BCA amendments may vary requirements. Users of this Guide should make themselves aware of these differences and should develop a full understanding of the resulting implications. This Guide should only be used on this basis.

How to use the Guide

The Guide is set out in accordance with a simple step-by-step process shown in Table 1. The steps are then used as the basis for headings throughout the rest of the document.

Taking a step-by-step approach reduces complex designs to manageable elements.

Table 1: Design process for sound- and fire-resistant timber-framed construction

Step 1 – High-Level BCA Design Issues

Determine the Class of building

Determine the basis for complying with BCA Performance Requirements, i.e. Deemed to Satisfy Provisions to be used

Determine the setout of separating walls between dwellings

Step 2 – Define BCA Sound Design Requirements

Utilise the Deemed to Satisfy Provisions for sound design

Determine sound-insulation requirements for separating walls

Step 3 – Improve and Upgrade Sound Performance

Attention to building design (space and form)

Address flanking noise

Strategies for improving sound performance

Step 4 – Define BCA Fire-Design Requirements

Utilise the Deemed to Satisfy Provisions for fire design

Determine the Fire Resistance Levels of wall

Step 5 – Sound- and Fire-Rated Timber Construction

Principles in fire/sound-rated timber construction

Select a fire/sound-rated timber-framed system

Detail the selected system, e.g. joints,

Step 6 – Further Design Assistance (Appendices)

Structural considerations, other BCA requirements, references, glossary

1

This Guide covers BCA Class 1a and 10a buildings. It's also relevant to Class 1b structures.

Refer BCA 1.0.9 and 1.2.2 to 1.2.4.

Step 1 – High-Level BCA Design Issues

The BCA is the regulatory framework for determining minimum construction requirements for all types of buildings in Australia. It contains different levels of detail that subsequently cause different levels of decision making to be made on a building project. A selection of high-level design issues relating to fire-resisting and sound-insulation construction are addressed in this section of the Guide.

1.1 Determine the Class of Building

The Building Code of Australia (BCA) contains mandatory Performance Requirements that apply to 10 primary classes of building. These classes are determined according to the purpose for which a given building will be used. The classes relevant to this Guide are:

- Class 1a attached dwellings each being a building separated by a fire-resisting wall including row houses, terrace houses, townhouses or villa units.
- Class 10a non-habitable buildings that are attached or in some way associated with the above Class 1a buildings including private garages, carports and sheds.

These classes are dealt with in Volume 2 of the BCA and so all future references to the BCA are made with relevance to this Volume. Other Class 1 buildings not specifically dealt with in this Guide, but which may still benefit from specific information contained within, include:

- Class 1 detached dwellings.
- Class 1b boarding houses, guest houses, hostels and similar buildings (Note: Class 1b buildings are defined as having a total floor area up to 300 m² and would not ordinarily have more than 12 people as residents).
- Both these types of building have no specific sound Performance Requirements in the BCA and only require fire-resisting construction where exterior walls have close proximity to an allotment boundary or close proximity to an adjacent building (refer to ABCB Housing Provision Standard 2022 Part 9.2).

Care is required to ensure that Class 1a buildings do not inadvertently have their building classification changed. Common causes of this are:

- Two or more dwellings sharing a common garage.
- Two or more dwelling sharing a common entrance.
- One dwelling construction overlapping onto another below.

1.2 BCA Compliance – Deemed to Satisfy Provisions or Alternative Solutions

BCA Performance Requirements can be achieved for the above building classes in two different ways:

- Deemed to Satisfy Provisions – a specific type of construction that is acknowledged as complying with the BCA's Performance Requirements. This includes ABCB Housing Provision Standard for fire and sound, as detailed in Volume 2 of the BCA.
- Performance Solutions – this means a solution not dealt with under Deemed to Satisfy Provisions and must be proven to satisfy BCA Performance Requirements. Suitable assessment methods are identified in the BCA.

The construction systems and details in this Guide comply with the Deemed to Satisfy Provisions by utilising the ABCB Housing Provision Standard in Volume 2. This part of the BCA directs the level of fire-resisting and sound-insulation construction that timber-framed construction must achieve in order to meet minimum BCA Performance Requirements. Approved BCA methods of assessment are then used to ensure that the timber-framed construction systems shown in this Guide comply with the levels required.

Two clear BCA conditions make it straightforward to deem external walls.

1.3 Fire and Sound Separation in Buildings

In order to prevent the spread of fire and provide sound insulation between buildings, there are key concepts used in the BCA's ABCB Housing Provision Standard including:

Separating Walls – Such walls separate the effects of fire and sound on adjoining Class 1a buildings by virtue of a common wall. The wall commences at the lowest floor level (or possibly ground level where a raised floor is involved) and finishes at either the underside of the roofing material or in some instances a set distance above the roof line (Figures 3 and 4). More specific conditions concerning separating walls are discussed later in this Guide.

External Walls – Such walls are important in protecting a building against spread of fire from external fire sources (Figures 3 and 4). These walls are deemed to occur where:

- 900 mm or less from an allotment boundary other than the boundary adjoining a road alignment or other public space; or
- 1.8 m or less from another building on the same allotment other than a Class 10 building or a detached part of the same Class 1 building.

More specific conditions concerning external walls are discussed later in this Guide.




Figure 3: Examples of a separating and external wall – plan view.




Figure 4: Examples of a separating walls and external walls – elevation view.

2

Addressing multiple sound sources is even more important in light of today's trend towards medium density housing.

Step 2 – Define BCA Sound-Design Requirements

Designing sound-insulated construction involves a process of understanding how the BCA's Performance Requirements translate into objective design parameters, as contained in the BCA's Deemed to Satisfy Provisions (i.e. ABCB Housing Provision Standard). This is then used as the basis for selecting appropriate timber-framed construction. Key issues determining sound design requirements are discussed in this Section of the Guide.

2.1 Utilising the Deemed to Satisfy Provisions for Sound Design

The BCA's Performance Requirements for sound insulation concern the use of separating walls between dwellings to sufficiently insulate against airborne sound transmission and impact noise. In order to understand these requirements it is important to differentiate between airborne and impact sound as shown in Figure 5.




Figure 5: Examples of impact and airborne sound.

2.1.1 Airborne Sound Transmission

Airborne sound transmission refers to sound waves that travel through the air and cause a building element to vibrate, radiating out on the other side of the wall. Methods used to reduce transmitted airborne sound generally use cavity (isolated) construction with bulk insulations to absorb the vibration.

Deemed to Satisfy construction that meets the above Performance Requirements is provided in the ABCB Housing Provision Standard part of the BCA (Refer to ABCB Housing Provision Standard Part 10.7.1).

2.1.2 Impact Sound Transmission

Impact sound refers to the sound arising from the impact of an object on a building element causing both sides of the building element to vibrate and generates sound waves. The primary method used to reduce impact noise is isolation from any adjoining building elements.

Generally, the BCA considers impact sound for walls separating a bathroom, sanitary compartment, laundry or kitchen in one dwelling from a habitable room (other than a kitchen) in an adjoining dwelling. Sound leakage at penetrations from service elements may compromise the performance of walls.

Proper sound insulation isn't 'bolted on'. It starts at the bottom and permeates every level of construction.

This requirement is generally achieved with discontinuous construction. Refer to Appendix C for a definition of discontinuous construction.

It is also important to understand how each type of sound is measured in order to select sound-insulated separating walls. The nomenclature used in the BCA's ABCB Housing Provision Standard is explained in Figure 6.




Figure 6: Methods of measuring airborne sound.

2.2 Determine Sound-Insulation Requirements In Separating Walls

Given the previous definitions, the required airborne and impact sound insulation levels, as interpreted from the BCA for Class 1a buildings, are provided in Table 2. In addition to these requirements, there are general installation requirements in the BCA (refer to ABCB Housing Provision Standard Part 10.7.3). A key issue here is that to achieve the required sound levels, walls must be sealed at junctions between the sound-insulated separating wall and any perimeter walls or roof covering. In addition, timber studs and perimeter members must be installed as follows:

- Studs must be fixed to top and bottom plates of sufficient depth to permit secure fixing of the plasterboard.
- Noggings and like members must not bridge between studs supporting different wall leaves.
- All timber members at the perimeter of the wall must be securely fixed to the adjoining structure and bedded in resilient compound or the joints must be caulked so there are no voids between the timber members and the wall, refer to lining manufacturer's installation recommendations.

Note: BCA requirements for timber-compatible material such as plasterboard should be viewed separately in the BCA (refer to ABCB Housing Provision Standard Part 10.7.3) and/or proprietary installation manuals.

Table 2: Minimum sound insulation requirements for separating walls.

SEPARATING WALL – Location and Penetrations	Discontinuous Construction Required	$R_w + C_{tr}$
Between a bathroom, sanitary compartment, laundry or kitchen and a habitable room (other than a kitchen) in an adjoining Class 1 building	YES	50
In all other cases, includes roof void and subfloor areas	NO	50
Duct, soil, waste and water supply pipes and storm water pipes that pass through a separating wall between Class 1 buildings:		
• if the adjacent room is habitable (other than kitchen)	NO	40
• if the room is a kitchen or any other room.	NO	25

2.3 Treatment of Services Relevant to Timber-Framed Construction

If a duct, soil, waste, water supply or storm water pipe serves or passes through a separating wall or is located in a separating wall, then the following conditions apply:

- A door or panel providing access to a duct or pipe required to be separated must not open into any habitable room other than a kitchen. In any other part, the door or panel must be firmly fixed so as to overlap the frame or rebate of the frame by not less than 10 mm and be constructed of:
 - wood, plasterboard or blockboard not less than 33 mm thick; or
 - compressed fibre-cement sheeting not less than 9 mm thick; or
 - other suitable material with a mass per unit area not less than 24.4 kg/m².
- If it is a water supply pipe, it must:
 - only be installed in discontinuous construction (double stud walls); and
 - in the case of a water supply pipe that serves one dwelling, not be fixed to the wall leaf on the side of any other dwelling and have a clearance not less than 10 mm to the other wall leaf.

Electrical outlets must be offset from each other in timber framing not less than 300 mm.

2.4 The Next Step

Having used the previous information to obtain a strong understanding of the minimum sound insulation requirements for separating walls, the next step is to either:

- Go to Step 3 to improve and/or upgrade sound performance, or
- Go to Step 4 find out about the BCA fire-resisting construction requirements.

3

Quiet dwellings command premium prices, so it may pay to exceed minimum sound performance standards.

Windows and doors can thwart the best wall systems, but there are smart acoustic solutions.

Step 3 – Improve and Upgrade Sound Performance

Sound performance can often be improved by simple attention to the form and spatial arrangement of the building design. In addition, many end users of dwellings often want higher sound performance than the minimum levels required in the BCA. As a result, this Step of the Guide focuses on ways of improving and upgrading sound performance.

3.1 Checking and Adjusting the Building Design to Reduce Sound Transmission

There are many aspects of Class 1a buildings that can reduce sound transmission by simply paying attention to thoughtful sound design (Figure 7).

3.1.1 Room Layout

Check that the room layout is beneficial rather than detrimental to sound transmission. Service rooms including bathrooms, laundries and kitchens create extra sound compared to living rooms and bedrooms. For instance, water movement through plumbing pipes and the vibration from washing machines and dishwashers create sound problems. It is therefore best for the service rooms in one dwelling to back onto the same rooms in an adjoining dwelling and should not back onto habitable rooms. Also, try to ensure entrances to dwellings are an appropriate distance from attached or adjacent dwellings.

3.1.2 Windows

Windows normally have lower sound insulation than the walls they are located within. As a result, high sound-rated wall systems may become ineffective by virtue of poorly sound-insulated windows. Where noise is unavoidable, consider one or more of the following:

- Use thicker glass or double glazing.
- Use fixed glazing in lieu of opening windows. (This may also require sound-insulated ventilation.)
- Locate windows so that they do not face noisy areas.
- Provide adequate separation between windows in adjoining dwellings.
- Reduce the area of windows in the facade.
- Fill voids between the wall frame and window frame with an appropriate acoustic sealant.
- Use acoustic sealing strips/gaskets around the edges of the openable sashes and the window frame.

3.1.3 Doors

As with windows, doors tend to be the weak link in sound-rated walls. Where sound-control is desired, solid core doors should be used. The top and sides of doors should have soft acoustic gaskets. Threshold closers at the bottom of the door or air seals will also reduce sound transmission. Sliding doors should be avoided where optimum sound-control is desired.

3.1.4 Services

The location and detailing of services are two of the most important considerations in controlling sound transmission in residential buildings.

Generally, services and service penetrations should not be located on separating walls but rather on internal walls or dedicated sound resistant service shafts. In all instances, service pipes should be located away from noise-sensitive parts of the dwelling such as bedrooms.

Combined sound insulation strategies generally yield better results than stand-alone measures.




Figure 7: Sound design practices in building layout.

3.1.5 Flanking Noise

Flanking noise is best addressed by:

- isolating of forming discontinuous elements from each other, i.e. resilient acoustic ties and discontinuous flooring
- placing absorptive material within sound rated cavities, or near floor/ceiling and wall junctions.

3.2 Strategies for Improving Sound Performance in Construction

The following strategies can be used to improve the sound insulation. Generally, it is not the use of one but a combination of strategies that gives the most economical solution.

Extra mass on the wall – The addition of mass is a simple yet important means of improving sound performance in timber-framed construction. At its simplest, this involves adding extra layers of material such as plasterboard or fibre-cement sheet to the separating wall system.

Use a wider wall (90 mm wall studs) – The wider the wall, the better its sound performance. This is particularly the case when trying to improve C_{r1} scores (being the modification factor for low frequency bass noise applied to R_w scores). The simplest way to do this is to use 90 mm wide studs instead of, say, 70 mm wide studs in a double stud wall system.

Upgrade batts in the wall – There are many different types and grades of insulation batts available. Sound-insulation specific batts are best, and in addition, higher density materials tend to outperform low density materials but as a minimum, batts with densities of 10 kg/m³ or greater are recommended.

Batts do much more than save energy.

Discontinuous flooring – By stopping the floor sheet, so that does not run under the separating wall framing or connected to the neighbours framing, will result in less vibration transfer and subsequently less impact sound (Figure 10).




Figure 8: Discontinuous floor sheet under separating wall – elevation view.

Batts in the floor at the wall/floor junction – Where the parallel joist layout (Figure 8) cannot be achieved, it is good practice to place extra sound-insulation batts between joists running along the separating wall (Figure 9). Much the same can be done at wall and ceiling intersections, but is only required where such insulation is not already provided across the entire ceiling area, such as for energy efficiency.




Figure 9: Improved acoustic performance by placing sound insulation at the floor and wall intersection.

Isolated support for stairs – Impact sound from stair usage typically vibrates its way into separating walls, creating a greater likelihood of sound passing across the wall into attached dwellings. The best way to prevent this is by isolating the support for the stair structure (Figure 10). Options include:

- using the stringers to support the stairs, at each floor level, without intermediate support from the separating wall in between, i.e. free standing
- using Newell posts rather than the separating wall to support the stair structure.




Figure 10: Isolating stair structure from separating wall – elevation view.

Batten out separating walls in wet area – In wet area construction, fire/sound rated walls can be compromised where bath and shower base units need to be recessed into the wall. A simple means of dealing with this is to batten out the separating wall (after fire essential linings have been applied) and then providing an additional lining over the top (Figure 11). The bath can then be installed into the batten space without affecting the fire- and sound-rated wall.




Figure 11: Battens out the false wall for services – elevation view.

3.3 The Next Step

The strategies and methods shown in this Step of the Guide may involve specialist proprietary systems that go beyond the scope of this publication. As a result, the next step is to either:

- go to proprietary system suppliers and ask for advice on how to integrate their systems with those discussed in this Guide, or
- go to Step 4 to find out about BCA fire-resisting construction requirements.

4

ABCB Housing
Provision Standard
Part 9

ABCB Housing
Provision Standard
Part 9.2

Step 4 – Define Fire-Design Requirements

Like sound, designing fire-resisting construction involves a process of understanding how the BCA's Performance Requirements translate into objective design parameters, as contained in the BCA's Deemed to Satisfy Provisions (i.e. acceptable construction practices). This is then used as the basis for selecting appropriate timber-framed construction. Key issues are discussed in this section of the Guide.

4.1 Utilising the Deemed to Satisfy Provisions for Fire Design

As discussed previously, this Guide focuses on meeting Performance Requirements concerning protection against the spread of fire between Class 1a buildings (adjacent to each other) and associated Class 10a buildings. Acceptable construction practices that are Deemed to Satisfy these requirements and of relevance to timber-framed construction, are set out in ABCB Housing Provision Standard Part 9 of the BCA. It provides Fire Resistance Levels and associated construction details for external walls and separating walls. Fire Resistance Levels represent a key requirement when selecting appropriate timber-framed construction systems for fire separation and therefore form the basis for ongoing discussion.

A Fire Resistance Level (FRL) expresses the minimum amount of time (in minutes) that a building element must resist a fire as defined by three separate components:

- Structural adequacy (ability to withstand loads)
- Integrity (in terms of containing smoke, flames and gases)
- Insulation (in terms of limiting the temperature on one side of the element getting through to the other side).

An example of the way that an FRL is expressed is: 60/60/60. Another example where not all components are required is: –/60/–. Application of this and related aspects of construction are discussed under the following headings.

4.2 Fire Resistance Levels of Wall Elements

4.2.1 External Walls

External walls are used to protect Class 1a buildings from external fire sources (Figures 1 and 2).

Specific requirements pertaining to this include:

- Must have walls with an FRL of not less than 60/60/60 when tested from the outside.
- Must have walls that:
 - extend to the underside of a non-combustible roof covering, or
 - terminate not more than 200 mm from the underside of the non-combustible roof covering and is sealed by non-combustible fascia, gutter or flashing, or
 - extend to the underside of non-combustible eaves lining.
- Must have openings in walls:
 - protected by non-openable fire window or other construction with an FRL of not less than –/60/–: or
 - protected by self-closing solid core doors not less than 35 mm thick.

Concessions

Specific construction is allowed to encroach on the 900 mm space between an external wall and the allotment's boundary or 1,800 mm space between the external walls of two buildings on the same allotment, such as non-combustible fascia, gutters, downpipes, pergolas, sun blinds (refer ABCB Housing Provision Standard Part 9.2.9 for details).

Windows in non-habitable rooms that face the boundary of an adjoining allotment may be used, if it is not less than 600 mm from that boundary or if it faces another building on the same allotment, the distance may be increased to not less than 1,200 mm from the neighbouring building. These windows if in a bathroom, laundry or toilet, must not have an opening more than 1.2 m². In other rooms, not a bathroom, laundry or toilet, the opening can not be greater than 0.54 m² and must be constructed with a steel-frame, have no opening sashes and be glazed with wired glass or translucent hollow glass blocks.

4.2.2 External Walls where Class 10A Buildings are Involved

The issue of external walls becomes more complicated where Class 10a buildings (such as garages) have an intervening influence between the fire source and the Class 1a building (refer ABCB Housing Provision Standard Part 9.2.4 for illustration of this). This potentially causes a redesignation of (fire-resisting) external wall location. Situations affected include where:

- a Class 10a building occurs between a Class 1a building and the allotment boundary
- a Class 10a building occurs between a Class 1a building and other buildings on an allotment
- Class 10a buildings must be separated on an allotment because of ramifications on attached or adjacent Class 1a buildings.

The BCA gives quite a detailed description of the many options available and reference to this is recommended.

4.2.3 Separating Walls

Separating walls are used to provide fire-resistance and sound insulation between attached Class 1a buildings (Figures 1 and 2). Specific requirements pertaining to this include:

- Must have walls with an Fire Resistance Level of not less than 60/60/60.
- Must commence at the footings or ground slab and extend up according to one of the following scenarios:
 - For a non-combustible roof covering the wall must extend to the underside of the roof (Figure 2). The wall must not be crossed by timber members (or other combustible building elements) other than roof battens (maximum 75 x 50 mm) or sarking. Voids between the top of wall and underside of roofing (i.e. between battens) must be filled with solid timber 75 mm thick (min), mineral wool or other suitable fire-resisting material.
 - For a combustible roof the wall must extend 450 mm above the roof as shown in Figure 2.
- Must address the potential spread of fire and acoustic flanking noise that can potentially occur where the end of a separating wall intersects with exterior walls that has a cavity, i.e. masonry veneer wall and the cavity of the latter walls acts as a passage for fire and noise. Here, the cavity must be no greater than 50 mm wide and packed at the wall intersection with fire-resistant mineral wool or other suitable fire-resisting material. The packing must be detailed to meet weatherproofing requirements, and further details are given in Step 5 of this Guide.
- Eaves, verandahs and similar spaces that are open to the roof space and are common to more than one Class 1a dwelling must be separated by a non-combustible vertical lining.
- For electrical cables, wires, switches, outlets, sockets or the like penetrating a separating wall, the wall at the penetration must achieve an Fire Resistance Level of 60/60/60 and comply with BCA Volume 2, Specification 1 Fire-resistance of building elements.
- Other conditions also apply including the spacing between certain penetrations; the accuracy of installation; the treatment of residual gaps between the wall and electrical fitments/cables; the treatment of cavity spaces behind electrical fitments with fire-resisting materials. These aspects are addressed in Step 5 of this Guide.

4.2.4 Combined External and Separating Wall

Where adjoining Class 1a buildings are stepped in height, there can be a situation where there is confusion over which part of the wall is a separation wall and which is an external wall (Figure 10). In these circumstances the BCA considers that the wall above the lower roof line is treated as a fire-rated external wall.




Figure 10: Stepped roof line in Class 1a buildings.

4.3 The Next Step

Having used the previous information to understand fire-resisting construction requirements in the BCA, go to Step 5 to select complying timber-framed construction.

5

Step 5 – Select Sound- and Fire-Rated Timber Construction Systems

This Step focuses on matching the previously discussed Acceptable Construction Practices for both sound (e.g. $R_w + C_{tr}$) and fire (e.g. FRLs) with appropriate timber-framed construction. This Step begins by explaining key principles used in timber-framed construction to address sound and fire needs. These principles are then presented in the form of integrated systems, e.g. timber-framed wall, floor and ceiling systems. Importantly, construction details are provided for each system in terms of fire/sound rated junctions between elements, penetrations in elements, stair construction details, treatment of services and similar situations.

5.1 Principles for Achieving Fire Resistance Levels in Timber-Framed Construction

5.1.1 Fire-Grade Linings Provide the Primary Source of Protection to Fire-Rated Timber-Framed Walls

The greater the number of layers, the greater the resistance to fire. This is evident when viewing the main fire-resistant timber framing systems described and shown in Section 5.2. Additional measures, as detailed below, are required at weak spots or breaks in the fire-grade linings that occur at intersections between wall, floor and ceiling elements. Corner laps and exposed edges in lining sheets present another area of concern. Extra attention is also needed at penetrations, openings and protrusions.

5.1.2 Construction Joints

In relationship to fire-resistance only Construction Joints are fire-grade materials used to close gaps in the construction that occur between fire-grade materials and at service penetrations. They restrict heat, smoke and gases from moving beyond a certain point in the construction. There are various situations where such gaps occur and so various options can be used to act as fire stop materials, including:

- fire-resisting mineral wool as shown in Figure 13
- fire-resisting sealant as shown in Figure 14.

More layers = better fire resistance.

Laps, edges, penetrations, openings and protrusions have the opposite effect.




Figure 13: Fire-resisting mineral wool – plan view.

By forming a char layer when it burns, solid timber can achieve the fire resistance of fire-grade linings.




Figure 14: Fire-resistant sealant – elevation view.

Solid timber can be used as construction joints as they can achieve the equivalent fire resistance as fire-grade linings. This is mainly used where linings stop at junctions between wall and/or floor elements. At these junctions, the width of the timber framework is unprotected by the linings and so extra studs, plates or joists are used to provide fire-resistance. This is possible because timber of a certain thickness forms an insulating char layer as it burns. This helps protect and slow the burning process for the remaining timber thickness. As a result, it is possible to predictably calculate how long the timber joint will last in a fire. Though this varies according to timber density and species, in general, the more pieces of solid timber added to the joint, the longer the joint will last. Common locations where solid timber is used include wall junctions and floor junctions (Figure 15).

For information on the details of this joints in common location, refer to Section 5.4.




Figure 15: Common location of timber blocks that act as construction joints – elevation view.

For treating weak spots, suitable sealants have fire and sound ratings.

5.2 Principles for Achieving Sound Insulation in Timber-Framed Construction

Increasing mass of wall and floor elements can be particularly useful in reducing airborne sound transmission. A simple and effective means of doing this is to increase the thickness of wall linings and this is often achieved with the above mentioned fire-grade linings.

Isolating one side of a wall element from the other. This is also known as decoupling and can be useful in reducing both airborne and impact sound. Of note, it serves to limit the noise vibration from one side of the wall to the other and is an inherent feature of double stud cavity wall construction.

Avoiding rigid connections between the opposing sides of isolated (decoupled) elements.

This limits the occurrence of sound bridges that would otherwise allow sound to transmit from one side of the wall to the other. If required for structural stability, sound-resilient structural connectors should be used and should generally only be used at each floor or ceiling level.

Using absorptive materials to fill wall cavities can reduce airborne sound transmission. Cellulose fibre, glass fibre, polyester or mineral wool is generally used for this purpose.

Sealing sound leaks at the periphery of wall and floor elements or where penetrations are made for electrical and plumbing services. This is particularly important because penetrations create a weak spot in the system. Flexible sealants are often used in such situations and often have both a fire and a sound rating which enables requirements to be met.

5.3 Sound- and Fire-Rated Wall Construction Systems

Timber-framed construction systems that have been developed to meet these fire and sound principles are shown in Figure 16 to Figure 18 and include:

- sound- and fire-resistant double stud walls, i.e. for separating walls (Figure 16)
- fire-resistant single stud, external clad walls (Figure 17)
- fire-resistant brick veneer external walls (Figure 18).

These and similar systems are commonly provided using proprietary lining and insulation products. Each product must be assessed in order to prove compliance with the BCA. As a result, only the main design themes are shown in the drawings below.




Figure 16: Fire- and sound-rated double stud separating wall systems – plan view.




Figure 17: Fire-rated external stud wall systems (outside only) – plan view.




Figure 18: Fire-rated external brick veneer wall systems (outside only) – plan view.

5.4 Solid-Timber Construction Joints

As explained in Section 5.1, solid timber is used as an equivalent to fire-grade linings, the more blocks used the greater the Fire Resistance Level achieved. This is an important means of making fire-resisting joints between wall, floor and ceiling elements in timber-framed construction. A variety of common situations are shown in Figures 19, 20, 21 and 22; each system shows different ways to maintain the walls' integrity and are dependent on the installers preference and available support to the linings.

5.4.1 Non-Rated Walls Abutting Fire- and Sound-Rated Walls

Timber blocks can be used to close off walls where internal non-rated walls abut fire- and sound-rated walls. The blocking can be in the form of studs. Where the non-rated internal wall is loadbearing, the timber blocks used to maintain fire resistance generally cannot be used to support load.




Figure 19: Junction between fire-rated and non-fire-rated and/or lower fire-rated wall – plan view.




Figure 20: Junction between fire-rated and non-fire-rated wall – alternative method using metal angles – plan view.

More solid timber blocks = greater fire resistance.

If fire strikes, floors must be able to collapse while leaving separating walls intact.

5.4.2 Non-Rated Floor Abutting Rated Wall

Non-rated floors interfere with the wall lining to the separating wall. In this case timber blocks can again be employed. The following details a number of options that can be utilised and are generally dependant on individual choice or the framing situation. No one option is preferred.

In all cases it is also important to note that in the event of a fire, the flooring and floor joists must be free to rotate away from the separating wall. This requires that the floor sheet or boards not to be continuous under the separating wall framing. It is recommended that separate packers be used, or the flooring is sawn in this region.

Solid-Timber Blocking

Blocking is to be solid timber and measure at least the joist depth. For a Fire Resistance Level of 60/60/60, the timber blocking thickness is to be minimum of 45 mm.




Figure 21: Joist parallel and perpendicular to wall, wall stud not continuous through junction – elevation view.




Figure 22: Wall stud continuous through the junction with timber blocks – elevation view.

Burning joists that are free to rotate don't snag the wall above.

Fire Pockets in Separating Wall

Another method is to create pockets within the separating wall that allow the joists to bear on the wall. This detail can be achieved by utilising a similar technique discussed for double joists (refer to section 5.4.2) where one continuous solid timber joist the same depth of the joist system provides the fire protection. Where it is required to be joined, it must be butted closely, and the joint must be at least 100 mm away from any fire pocket formed.

The floor joists, being solid timber, I-beams or floor trusses, can now bear onto the top of the wall. Between the joists, additional solid-timber blocks the same depth and thickness as the inner blocking are to be tightly cut-in. The main floor joists are not to be nailed to blocking, any nailing is to occur at the base of the joist into the wall plate only. The timber packer directly above the joist that sits in the pocket is to be removed for the pocket portion width. This is to allow the joist to rotate in a fire event and not catch the bottom of the wall above (Figures 23 and 24).




Figure 23: Fire pockets in separating wall – elevation view.




Figure 24: Pockets created in separating wall to accommodate floor joists – perspective view from above.

Top Chord Support Detail for Floor Truss

Floor trusses are commonly used as floor joists. This form of floor joist has the unique ability to be top chord supported. A similar support mechanism as the pocket described above can be used. Here only the top chord needs to be pocketed (Figure 25). An alternative method is to form a ledger to support the floor truss top chord (Figure 26).




Figure 25: Floor truss top chord support in pockets – elevation view.




Figure 26: Floor truss top chord support on timber block – elevation view.

**Separating walls
must be fully
grounded.**

5.4.3 Lowest Floor and Subfloor

Where the lowest floor is elevated off the ground there is a requirement to continue the separating wall to the ground. Typically, a concrete or masonry plinth that is at least 75 mm higher than the finished ground level can be utilised.

Where the floor intersects with the separating wall, the construction details to maintain fire and sound resistance are similar to the junction of floors at the first floor level. Care is required to ensure construction in the subfloor region is durable for the location (Figure 27).




Figure 27: Subfloor details – elevation view.

5.5 Treatment of Roof Voids

As mentioned in Section 3.2, there is the possibility of fire and sound jumping from one dwelling to another through the roof void. To prevent this occurring in timber-framed construction, the fire/sound wall is continued through the roof void to the roof covering.

5.5.1 Roof Framing or Trusses Parallel to Separating Wall

Where the roof framing is parallel with the separating wall there are no special details other than to allow enough room to install the fire-grade linings (Figures 28 and 29).




Figure 28: Double stud fire/sound rated wall in roof cavity – elevation view.




Figure 29: Separation wall above the roof line – elevation view.

5.5.2 Roof Framing or Trusses Perpendicular to Separating Wall

Where roof framing or trusses are perpendicular to the separating wall they need to be supported off the wall by the use of timber blocks as discussed for floor joists. The same technique can be utilised here (Figures 30 and 31).




Figure 30: Trusses or roof framing support off separating wall – elevation view.





Figure 31: Typical box gutter detail at the top of separating wall – elevation view.



5.5.3 Eaves and Verandah Roof Voids

Where eaves and verandah roofs are open to the roof space and are common to more than one dwelling, the roof void is required to be separated by non-combustible linings. This separation can be achieved by the inclusion of fibre-cement or plasterboard lining to one side of the framing as shown in Figure 33 or closing of the space back to one of the dwellings as shown in Figure 34 (ABCB Housing Provision Standard Part 9.3.1 (5)).

*These days,
roof 'voids' are
anything but!*




Figure 33: Eaves blocking – front elevation view.




Figure 33a: Eaves blocking – side elevation view.

Cavity materials must be fire resistant and durable.




Figure 34: Sealing of eaves or verandah voids.

5.6 Separation Wall Abutting External Walls

The BCA requires that the junction of the sound-insulated separating wall with the exterior wall or roof cladding must be sealed with mineral wool or other fire-resisting material (ABC Housing Provision Standard Part 9.3.1 (4)).

5.6.1 Brick Veneer Cavity

The gap formed at the end of the separating wall and the external brick skin of the brick veneer wall requires fire-resistant construction. Timber blocks are used to extend the separating wall to the cavity. Within the cavity the materials used must be fire-resistant and durable. Figure 35 details fire-resistant mineral wool and a moisture break between the brick skin and the fire-resistant material is required.




Figure 35: Fire-resistant mineral wool in brick veneer cavity – plan view.

5.6.2 Separating Walls at Staggered External Wall Alignments

Where dwellings are offset to each other, the separation wall becomes an external wall, as shown in Figure 36, the fire resistance requirements change from a separating wall to an external wall. The external wall fire resistance requirements necessitate fire rating from the outside, while the separating wall requires fire rating in two directions. Therefore the requirement of fire grade plasterboard to the inside wall of the external wall is not needed, but it is recommended that it is continued, to avoid a mismatch of wall sheet thickness.




Figure 36: Additional blocking in offset dwellings – plan view.

5.6.3 Lightweight Wall

For lightweight walls, timber blocking is only required to extend the separating wall to the exterior lining (Figure 37).




Figure 37a: Lightweight walls – plan view.




Figure 37b: Lightweight walls – alternative detail – plan view.

5.6.4 Staggered Roof Linings at Separating Walls

Where the separating wall in one dwelling continues beyond the roof linings of a neighbouring dwelling, the wall above the lower adjacent dwelling is now considered to be an external wall (ABCB Housing Provision Standard Part 9.2, Figure 9.2.2e). Fire-rating requirements of the external only require fire resistance from the outside. However, it is recommended to continue the fire-rated linings on the inside of the external wall to avoid a mismatch of lining thickness (Figure 38).




Figure 38: Staggered roof lines meeting at a separating wall – elevation view.

5.7 Steel Columns in Separating Walls

In modern living there is often a need to provide large openings. In typical timber-framed townhouse construction there may be a large opening at the end of the building spanning between separating walls, supporting brickwork above.

Often it is desirable to enclose the beam and its support within the timber framing, meaning that the steel beam column supports are often housed in the separating wall. This creates a complication in maintaining fire resistance as the steel beam is normally not fire protected, and during a fire, the steel beam may collapse and impair the separating wall.

To account for this, testing has been carried out to design a steel beam and its column enclosed within the wall. To achieve this outcome it is necessary to create a pocket for the steel beam to sit within the wall. Then, during a fire, the beam may rotate out of the pocket, leaving the separating wall intact.

This pocket is achieved by sitting the steel beam on top of the column with no physical connection other than bearing. The column is located by the surrounding timber framing, and is fire protected as the fire-rated linings run pass the column face.

Steel beams can create complications, but solutions are at hand.

The beam sits in its own created pocket with timber framing surrounding it. Fire safety is achieved by using fire-resistant mineral wool packed in and around the beam. A metal flashing is placed at the back of the pocket to seal the pocket from the separation wall cavity.

Directly above where the beam will sit in the pocket it is necessary to leave a minimum of 20 mm gap to allow this rotation of the beam. Normally this could simply be achieved by removing the floor sheet or packer at this location. Again fire-resistant mineral wool is placed in this void to maintain the fire rating. Figure 39 is a detailed cut away view of the framing and columns and Figure 40 contains more precise detail information.




Figure 39: Cut away view of steel beam and column housed in a timber-framed separating wall – perspective view from above.




Figure 40a: Details of the steel beam pocket in timber-framed separation wall – elevation view.




Figure 40b: Details of the steel beam pocket in timber-framed separation wall – elevation view.




Figure 40c: Details of the steel beam pocket in timber-framed separation wall – plan view showing one wall leaf only.

5.8 Horizontal Projection of a Floor and Separating Wall in Neighbouring Buildings

The BCA requires (ABC Housing Provision Standard Part 9.3.4) any horizontal projection, such as a second storey, that contains a part of a separating wall dividing two dwellings (Figure 41), to have additional fire resistance to the underside of the projected part, at least, 1.8 m from the separating wall.




Figure 41: Added fire resistance to projected separating wall.

The fire resistance to the underside of the projection within 1.8 m from a separating wall, can be either;

- floor/ceiling or floor/soffit system incorporating a 60 minutes resistance to the incipient spread of fire ceiling or soffit. The incipient spread of fire ceiling or soffits, normally contain fire-rated linings, and details of this system can be found from lining manufacturers, or
- have an FRL of not less than 30/30/30 when tested from the underside, or
- have a fire-protective covering on the underside of the projection including any beams incorporated into the projection. A fire-protective covering is either
 - 13 mm fire-protective grade plasterboard; or
 - 12 mm fibre cement; or
 - 12 mm fibrous plaster reinforced with 13 mm x 13 mm x 0.7 mm galvanised steel wire mesh located not more than 6 mm from the exposed face; or
- other material not less fire-protective than 13 mm fire-protective grade plasterboard.

The BCA also requires the part of the separating wall that projects horizontally must extend to the underside of the non-combustible roof, or extend 450 mm above the roof. The top of the wall is also not to be crossed by timber greater in size than 75 x 50 mm, and any gaps between the roof covering or external wall envelope packed with mineral wool or timber blocks that maintain the fire rating. Any service that passes through the protection must not reduce the fire performance of the FRL, fire protective covering or resistance to the incipient spread of fire ceiling.

Furthermore, where the fire protection solution used is the system requiring an FRL 30/30/30, then where the floor/ceiling system requires direct vertical or lateral support to maintain the FRL, then the supporting part must also have an FRL of 30/-/-. The fire resistance to the supporting structure can be achieved by encapsulating a wall, post or beam with fire grade plasterboard, or if it is timber post or beam, design the FRL by using AS/NZS 1720.4, the effective depth of charring.

To avoid the need of additional fire resistance due to support of another part, use the fire protective covering option

5.9 Fire Separation of Garage Top Dwellings

Note: This section is not applicable to NSW, where there are different and additional requirements.

Where there are more than one Class 1a dwellings on the one allotment, the BCA (ABC Housing Provision Standard Part 9.4.1 and 9.4.2) has additional requirements when parts of one dwelling are located above a garage associated with another dwelling (Figure 42). In this situation, additional fire resistance is required between the dwelling and the garage not associated with the dwelling.




Figure 42: Separating floor and wall construction.

The wall that separates the garage not associated with the dwelling or the dwelling's garage is required to have an FRL of 60/60/60 and extend from footing or ground slab to the underside of the separating floor. Furthermore, a separating floor is required between the garage not associated with the dwelling and the dwelling. The separating floor can be a ceiling that has a Resistance to Incipient Spread of Fire (RISF) of 60 minutes, or a have an FRL of 30/30/30 or have a fire protective covering consisting of

- 13 mm fire-protective grade plasterboard; or
- 12 mm fibre cement; or
- 12 mm fibrous plaster reinforced with 13 mm x 13 mm x 0.7 mm galvanised steel wire mesh located not more than 6 mm from the exposed face; or
- other material not less fire-protective than 13 mm fire-protective grade plasterboard.

Where a separating floor solution of FRL 30/30/30 is chosen, and the floor requires direct vertical or lateral support to maintain the FRL, then the supporting part must have an FRL of 30/-/. Where any services pass through the floor, the services must not reduce the fire performance of the FRL, fire protective covering or RISF ceiling.

6

Step 6 – Further Design Assistance (Appendices)

The previous Steps in the Guide require consideration of additional information on topics closely linked to the design of fire- and sound-rated construction. The following appendices cover structural design considerations, Deemed to Satisfy fire requirements not covered by this Guide, other design references and a glossary.

Appendix A – Resolving Structural Design Considerations and Construction Practices

Loads, timber member sizes and construction practices not described in the Guide should be determined in accordance with AS 1684 – Residential Timber-Framed Construction Standard.

In designing stud sizes for fire-rated walls, it is necessary to consider a special load condition for fire. This special load condition for fire is another load condition required by the loading and timber engineering standards. In most cases, the wall systems offered by three plasterboard lining manufacturers (CSR Gyprock, Knauf, and Siniat) are not sensitive to the fire load condition, as long as the walls are laterally supported at a maximum of 3.0 m intervals, discussed in more detail below. The assessment (Exova Warringtonfire RIR 22567A-05) that supports this statement is available from the WoodSolutions website.

For other manufacturers of plasterboard or different lining types, the sensitivity of the fire load case and timber stud sizes vary from manufacturer to manufacturer and lining type. As this Guide does not go into the particular design details of proprietary systems, a reference to the provider of the fire-rated wall system is required to ensure this fire condition design is satisfied or is required.

A key consideration is the need for fire-load design as the lateral support from the floor and ceiling structure cannot be taken into account when it is from the potentially fire-affected side. As separating walls are normally double stud, there will potentially be no lateral restraint to the entire wall height, i.e. on the fire side of the separating wall. This is due to the floor or ceiling framing on one side of the wall is designed to rotate away from the separating wall during a fire, without dragging the wall with it. This means that under the fire event, the separating wall can stay in place to carry structural loads and retain the fire-resistant linings.

The 3.0 m height reflects the maximum height fire testing of walls is typically undertaken. As a result, extra structural support is required in the wall system to deal with the gap between theoretical assumptions and what is achievable in practice. In a double stud wall construction, this is commonly dealt with under the assumption that the non-fire affected side of the wall will remain laterally restrained by the first floor and ceiling, even though the floor on the (other) fire-affected side has burnt and rotated away.

Resilient structural connectors are then used to hold the fire-affected side of the wall, to the non-fire affected side. Such ties are typically placed at each floor and ceiling level (only) as the BCA requires discontinuity of lightweight walls except at their periphery. It is important that these ties be acoustic ties¹ in order to prevent sound transmission across the wall structure. Such ties are typically placed at 1200 mm spacings (Figure A1).

Ties at the roofline are normally achieved by the tile or roof sheet battens. The BCA limits the batten size to a maximum of 70 x 50 mm. Where battens are not tying the top of the wall, additional ties will be required.

It is also important to note to allow this rotation of the flooring away from the separating wall requires that the floor sheet or boards not be continuous under the separating wall framing. It is recommended that separate packers be used under the bottom plate, or the flooring is saw cut in this region.

It's ironic that the best structural designs pay heed to their possible destruction.




Figure A1: Structural and acoustic ties used to laterally support the separating wall – elevation view.

Appendix B – Design References

Design References

Australian Building Codes Board

- Building Code of Australia (BCA) 2009 – Volume 1 & 2.
- ABCB Housing Provision Standard

Australian Standards

- AS 1530.4 – Methods for fire tests on building materials, components and structures – Fire-resistance tests on elements of construction.
- AS 1684 – Residential Timber Framed Construction Standard.
- AS/NZS 2908.2 – Cellulose cement products – Flat sheets.
- AS 4072.1 – Components for the protection of openings in fire-resistant separating elements – Service penetration and control joints.
- AS/NZS 1720.4 Timber structures - Part 4: Fire resistance of timber elements

Australian, New Zealand and International Standard

- AS/NZS ISO 717.1 Acoustics – Rating of sound insulation in buildings and of building elements – Airborne sound insulation.
- AS/NZS ISO 717.2 Acoustics – Rating of sound insulation in buildings and of building elements – Impact sound insulation

WoodSolutions

The following publications are available as free downloads at woodsolutions.com.au:

- #02 Timber-Framed Construction for Multi-Residential Buildings Class 2, 3 and 9c – Design and construction guide for BCA compliant sound- and fire-rated construction
- #03 Timber Fire Design Compliance for Low-rise Office (Class 5) and School (Class 9) Buildings

Test and Assessment Reports

Bodycote Warringtonfire (Aus)

- 22567A Assessment Report: The likely fire resistance performance of timber-framed walls lined with plasterboard if tested in accordance with AS 1530.4 2005, September 2008.
- 22567B Assessment Report: The likely fire resistance performance of MRTFC wall floor junctions if tested in accordance with AS 1530.4 2005, September 2008.
- RIR 22567B Regulatory Information Report: The likely fire resistance performance of MRTFC wall floor junctions if tested in accordance with AS 1530.4 2005, September 2008.
- 2256701 Test Report: Fire resistance test of a timber wall floor junction in general accordance with AS 1530.4 2005, September 2008.
- 2256702 Test Report: Fire resistance test of a wall beam junction when tested in general accordance with AS 1530.4 2005, September 2008.

Exova Warringtonfire Australia

- 2365300 Test Report: Fire resistance test of floor junctions incorporating timber and plasterboard in general accordance with AS 1530.4 2005, November 2009.
- 2365400 Test Report: Fire resistance test of floor junctions incorporating timber and plasterboard in general accordance with AS 1530.4 2005, November 2009.
- 2365500 Test Report: Fire resistance test of floor junctions incorporating timber and plasterboard in general accordance with AS 1530.4 2005, November 2009.

Free resources
available at
woodsolutions.com.au

Appendix C – Glossary

BCA

Building Code of Australia (BCA) 2022 – Volume 2 - Class 1 and 10 Buildings.

Cavity barrier

A non-mandatory obstruction installed in concealed cavities within fire-rated wall or floor/ceiling systems.

Discontinuous construction

A wall system having a minimum of 20 mm cavity between two separate wall frames (leaves) with no mechanical linkage between the frames except at the periphery i.e. top and bottom plates.

Construction joint

Discontinuities of building elements and gaps in fire-rated construction required by the BCA to maintain fire resistance. Refer to Deemed-to-Satisfy Provision C3.16, Volume 1, BCA.

Exit

Includes any of the following if they provide egress to a road or open space:

- an internal or external stairway
- a ramp complying with Section D of the BCA
- a doorway opening to a road or open space.

Fire-grade lining

Either fire-grade plasterboard, fibre-cement or a combination of both, used to provide the required Fire Resistance Level (FRL) for walls or floor/ceiling systems. Individual linings manufacturers should be contacted to determine the extent to which a given lining material provides fire-resisting properties.

Fire-isolated stair or ramp

A Stair or ramp construction of non-combustible materials and within a fire-resisting shaft or enclosure.

Fire-isolated passageway

A corridor or hallway of fire-resisting construction which provides egress to a fire-isolated stairway or ramp.

Fire-protective covering

- 13 mm fire-grade plasterboard; or
- 12 mm cellulose fibre-reinforced cement sheeting complying with AS 2908.2; or
- 12 mm fibrous plaster reinforced with 13 mm x 13 mm x 0.7 mm galvanized steel wire mesh located not more than 6 mm from the exposed face; or
- Other material not less fire-protective than 13 mm fire-grade plasterboard.

Note: Fire-protective covering must be fixed in accordance with normal trade practice (e.g. joints sealed).

Fire Resistance Level (FRL)

The period of time in minutes, determine in accordance with Specification 1 and 2 (of the BCA) for the following:

- Structural adequacy
- Integrity
- Insulation.

Mineral wools are not all the same. Check product sheets to ensure correct fusion temperature.

Fire-resisting mineral wool

Compressible, non-combustible, fire-resisting material used to fill cavities and maintain fire resistance or restrict the passage of smoke and gases at gaps between other fire-resisting materials.

Note: The mineral wool to be used in all applications in this manual, must be fire-resisting and therefore must have a fusion temperature in excess of 1160° C. 'Rockwool' type products generally meet these requirements, while 'glasswool' products do not.

Fire-resisting (Fire-rated)

As applied to a building element means, having the FRL required by the BCA for that element.

Fire-resisting construction

Construction which satisfies Volume 2 of the BCA.

Fire-resisting junction

The intersection between a fire-rated wall or floor/ceiling system and or another rated or non-rated system, which maintain the fire resistance at the intersection.

Fire-resisting sealant

Fire-grade material used to fill gaps at joints and intersections in fire-grade linings to maintain Fire Resistance Levels.

Note: The material should also be flexible to allow for movement and where required waterproof as well.

Fire-source feature

Either:

- the far boundary of a road adjoining the allotment; or
- a side or rear boundary of the allotment; or
- an external wall or another building on the allotment which is not of Class 10.

Habitable room

A room for normal domestic activities and includes a bedroom, living room, lounge room, music room, television room, kitchen, dining room, sewing room, study, playroom, family room and sunroom, but excludes a bathroom, laundry, water closet, pantry, walk-in wardrobe, corridor, hallway, lobby, clothes-drying room, and other spaces of a specialised nature occupied neither frequently nor for extended periods.

Internal walls

Walls within, between or bounding separating walls but excluding walls that make up the exterior fabric of the building.

NOTE: Fire walls or common walls between separate buildings or classifications are NOT internal walls.

Lightweight construction

Construction which incorporates or comprises sheet or board material, plaster, render, sprayed application, or other material similarly susceptible to damage by impact, pressure or abrasion.

Non-combustible

Applied to a material not deemed combustible under AS 1530.1 – Combustibility Tests for Materials; and applied to construction or part of a building – constructed wholly of materials that are not deemed combustible.

Performance Requirements

The objectives, functional statements and requirements in the Building Code of Australia that describe the level of performance expected from the building, building element or material.

 R_w

Refer to Weighted sound reduction index.

Unit

Sole-Occupancy unit.

Weighted sound reduction index (R_w)

The rating of sound insulation in a building or building element as described in AS/NZS ISO 717.1 .

Notes

[illegible]

Notes

[illegible]

**Now
available
for free
download**

Collect the full set of resources for your library

Over 50 technical guides cover aspects ranging from design to durability, specification to detailing. Including worked drawings, they are an invaluable resource for ensuring timber-related projects comply with the National Construction Code (NCC). Download them now from WoodSolutions.com.au, the website for wood.

- 1 Timber-framed Construction for Townhouse Buildings Class 1a
- 2 Timber-framed Construction for Multi-residential Buildings Class 2 & 3
- 3 Timber-framed Construction for Commercial Buildings Class 5, 6, 9a & 9b
- 4 Building with timber in bushfire-prone areas
- 5 Timber service life design - design guide for durability
- 6 Timber-framed Construction - sacrificial timber construction joint
- 7 Plywood box beam construction for detached housing
- 8 Stairs, balustrades and handrails Class 1 Buildings - construction
- 9 Timber flooring - design guide for installation
- 10 Timber windows and doors
- 11 Timber-framed systems for external noise
- 12 Impact and assessment of moisture-affected, timber-framed construction
- 13 Finishing timber externally
- 14 Timber in Internal Design
- 15 Fire Design
- 16 Massive Timber Construction Systems: Cross-Laminated Timber (CLT)
- 17 Alternative Solution Fire Compliance, Timber Structures
- 18 Alternative Solution Fire Compliance, Facades
- 19 Alternative Solution Fire Compliance, Internal Linings
- 20 Fire Precautions During Construction of Large Buildings
- 21 Domestic Timber Deck Design
- 22 Thermal Performance in Timber-framed Buildings
- 23 Using Thermal Mass in Timber-framed Buildings
- 24 Thermal Performance for Timber-framed Residential Construction
- 25 Rethinking Construction - Consider Timber
- 26 Rethinking Office Construction - Consider Timber
- 27 Rethinking Apartment Building Construction - Consider Timber
- 28 Rethinking Aged Care Construction - Consider Timber
- 29 Rethinking Industrial Shed Construction - Consider Timber
- 30 Timber Concrete Composite Floors
- 31 Timber Cassette Floors
- 32 EXPAN Long Span Roofs - LVL Portal Frames and Trusses
- 33 EXPAN Quick Connect Moment Connection
- 34 EXPAN Timber Rivet Connection
- 35 EXPAN Floor Diaphragms in Timber Buildings
- 36 EXPAN Engineered Woods and Fabrication Specification
- 37 Mid-rise Timber Buildings (Class 2, 3 and 5 Buildings)
- 37R Mid-rise Timber Buildings, Multi-residential (Class 2 and 3)
- 37C Mid-rise Timber Buildings, Commercial and Education Class 5, 6, 7, 8 and 9b (including Class 4 parts)
- 38 Fire Safety Design of Mid-rise Timber Buildings
- 39 Robustness in Structures
- 40 Building Timber-framed Houses to Resist Wind
- 41 Timber Garden Retaining Walls Up to 1m High
- 42 Building Code of Australia Deemed to Satisfy Solutions for Timber Aged Care Buildings (Class 9c)
- 43 Reimagining Wood-based Office Fitout Systems - Design Criteria and Concepts
- 44 CLT Acoustic Performance
- 45 Code of Practice - Fire Retardant Coatings
- 46 Wood Construction Systems
- 47 Timber Bollards
- 48 Slip Resistance & Pedestrian Surfaces
- 49 Long-span Timber Floor Solutions
- 50 Mid-rise Timber Building Structural Engineering
- 51 Cost Engineering of Mid-rise Timber Buildings